

Triton TX – DTS Touch Screen Calibration Instructions

Quick Access Method (This is the preferred method for end users)

1. Turn unit off.
2. While holding stop and pause buttons down (keep holding), turn unit back on.
3. An x should appear in the upper left corner.
4. Touch the x and it will move to upper right corner.
5. Keep touching the x until it is in the lower left corner.
6. With the tip of your finger trace a line around the edge of the screen.
7. When line looks good to you push accept.
8. Calibration should be done.

Access Method in Service Manual

1. Turn unit off.
2. While holding start and stop buttons down (keep holding), turn unit back on.
3. Wait until 2nd red square appears on screen then release buttons.
4. Screen should read, zeroing load cell, touch screen anywhere to continue.
5. Screen should read CG technician utilities.
6. Push button reading calibrate touch screen.
7. An x should appear in the upper left corner.
8. Touch the x and it will move to upper right corner.
9. Keep touching the x until it is in the lower left corner.
10. With the tip of your finger trace a line around the edge of the screen.
11. When line looks good to you push accept.
12. Calibration should be done.