

Triton and TX – Zero Load Cell Procedure

Models 2841, 4739, 4759

This procedure is used for some of the following symptoms: the traction rope feeding out of the machine, Error 309 and some other anomalies.

1. To zero the load cell, simply turn off the unit at the power switch on the back.
2. With one hand, hold down the Start and the Stop buttons, located below the touch screen.
3. Keep holding these down as you turn on the machine.
4. Hold them continuously for about 15 - 20 seconds, until the unit beeps.
5. During this time, the unit will go through several stages.
6. After the beep, the CO Technicians Utilities Screen should appear, being a blue screen with a yellow stripe across the top.
7. Release the Start and Stop buttons.
8. Select "Zero the Load Cell" from the menu by touching the second button from the left on the top row of the screen.
9. Wait a few seconds for the zero process.
10. When it is complete, the unit will display "... Touch anywhere to continue".
11. Touch the screen and resume normal use.